BASELINE (BL, BL25) - DC ELECTRICAL CONNECTIVITY

CAUTION: BEFORE CONNECTING THE FIXTURE TO A POWER SUPPLY, MAKE SURE THE POWER IS SWITCHED OFF.





corporate


- t (877) SSL-GREEN
- f (630) 889-8106 3609 Swenson Ave. St. Charles, IL 60174

DETAILED ILLUSTRATION


GENERAL:

- Before starting the installation, make sure all electricity has been turned off and electrical breaker has been locked out and tagged out.
- To ensure the success of the installation, be sure to read these instructions and review the diagrams thoroughly before beginning.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electrical Code.

NOTE: The important safeguards and instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur.



NOTE: EN250 (250W) or EN100 (100W) can be used as power supply.



JO Rev 1117